

mini kaoss pad 2 Ver.1.08 Release Information

Changes in Ver. 1.08 from Ver.1.06

- A few low-level software bugs have been fixed.


What you will need

- Memory card supported by mini kaoss pad 2
- Computer with memory card adapter
- AC adapter KA191 or two AA batteries.

 Make sure the batteries are brand new if using alkaline or fully charged if using NiMH batteries.

Updating the software

1. Prepare a memory card that has been formatted by mini kaoss pad 2.
2. Insert the memory card into your card reader, and connect it to your computer.
3. Extract minikaosspad2_xxxx.zip.
4. Copy “MINIKP2.BIN” into the [SYSTEM] folder under the [MINIKP2] folder on the memory card.
5. Insert the memory card containing the new system file into your mini kaoss pad 2, and turn on the power.
6. Select “SOFTWARE UPDATE” from the Utility menu. Tap YES using the VALUE slider.



7. A confirmation message will appear. Tap YES to begin the update operation.
⚠ **Do not turn off mini kaoss pad 2 while update is in progress.**



8. mini kaoss pad 2 will display the following screen when update is complete.



9. Tap the VALUE slider. mini kaoss pad 2 will now turn off. The system has been updated.