mini kaoss pad 2 Ver.1.10 Release Information

Changes in Ver. 1.10 from Ver.1.08

- The BPM page and the AUTO BPM page are added to the setup menu.

Page	Item	Content	Default value
P-1/8	MIXER	Adjusts the playback volume of the audio input and the audio player playback.	--
P-2/8	BPM	Specifies the tempo to be used by programs such as delay.	120
P-3/8	AUTO BPM	Selects a song, the one being played back by the audio player (PLAYER) or the one inputted from the LINE IN jack (LINE IN), from which a beat is detected automatically, or disables this function (OFF).	OFF
P-4/8	FX DEPTH	Adjusts the effect depth.	100
P-5/8	FX RELEASE	Specifies how the effect will remain when you turn off the effect.	Enable
P-6/8	CONNECTION	Specifies whether the audio input and the effect sound will be mixed for output.	Direct
P-7/8	MASTER RECORDER	Records your mini kaoss pad 2 performance onto the memory card.	--
P-8/8	UTILITY	Tap the center of the VALUE slider to enter the UTILITY menu selections.	--

- A few low-level software bugs have been fixed.

What you will need

- Memory card supported by mini kaoss pad 2.
- Computer with memory card adapter.
- AC adapter KA19x or two AA batteries.

Make sure the batteries are brand new if using alkaline or fully charged if using NiMH batteries.

Updating the software

1. Prepare a memory card that has been formatted by mini kaoss pad 2.
2. Insert the memory card into your card reader, and connect it to your computer.
3. Extract minikaosspad2_????.zip.

   Always extract all the files in the ZIP file before proceeding to step 4. If you perform the next step without extracting the ZIP file, the required files might not be found.

4. Copy “MINIKP2.BIN” into the [SYSTEM] folder under the [MINIKP2] folder on the memory card.
5. Insert the memory card containing the new system file into your mini kaoss pad 2, and turn on the power.

   While the power is on, do not insert or remove the memory card. Failure to observe this can result in a failure in the update.

6. Select “SOFTWARE UPDATE” from the Utility menu. Tap “YES” using the VALUE slider.

7. When you tap it, the update confirmation screen and the current system version number will appear. A confirmation message will appear. Tap “YES” to begin the update operation.

Do not turn off mini kaoss pad 2 while update is in progress.

8. mini kaoss pad 2 will display the following screen when update is complete.

9. Tap the VALUE slider. mini kaoss pad 2 will now turn off. The system has been updated. After a restart, choose the SOFTWARE UPDATE screen in the utility menu to check that the latest system version number is displayed.